

ANIMATED POP-UP CRYPT REAPER™

Rises to 8 in. (H)
20.32cm

- For indoor use only
- Animated, sound and motion activated
- Requires 3 AA batteries (included)

BATTERY INSTRUCTIONS & CAUTIONS

REQUIRES 3
AAA BATTERIES
(included for demo
purposes only).



- Battery installation and removal should be performed by an adult.
- Remove batteries when not in use.
- Use only batteries recommended in the instructions.
- Do not mix new and used batteries.
- Do not mix alkaline, carbon-zinc, nickel-cadmium, rechargeable or different types of batteries.
- Be mindful to insert batteries with the correct polarity (+/-) as indicated.
- Remove all exhausted batteries.
- Rechargeable batteries are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the item before being charged.
- Non-rechargeable batteries are not to be recharged.
- The supply terminals are not to be short-circuited.
- Always dispose of exhausted batteries properly.
- Do NOT dispose of batteries in fire, they may leak or explode.

⚠ WARNING! CHOKING HAZARD - small parts.

This item is not a toy. For decoration only.
This product is intended for use by persons 15 years of age and older.
Not intended for use by children 14 years of age and younger.

OPERATING INSTRUCTIONS

KEEP ALL PLASTIC AND WIRE PARTS AWAY FROM CHILDREN

1. Carefully remove and discard the "Try Me" wire and packaging.
2. Insert 3 brand new AAA alkaline batteries into the battery compartment located on bottom of the ANIMATED POP-UP CRYPT REAPER™.

3. Turn switch to the "ON" position.

4. Make a loud sound (clap), or wave hand in front of item to activate the scary sequence!

NOTE: Keep switch in the "OFF" position when not in use.

WIPE WITH CLOTH.

All new materials: plastic, metal, electronic material, fiber.

Item #59033. ANIMATED POP-UP CRYPT REAPER™ is a trademark of Tekky.
Copyright © 2024 Tekky. All rights reserved. MADE IN CHINA.

TekkyDesign.com

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Importer: Big Lots Stores, Inc. Address: P.O. Box 28523, Columbus, OH 43228-0523
Telephone number: (708) 478-7323