Surface Washable Only.

All new materials: polyester, plastic, wire FLYING REAPER™ is a trademark of Tekky. Copyright © 2018 Tekky. All Rights Reserved. MADE IN CHINA

FLYING REAPER


OPERATION INSTRUCTIONS:

- Remove heavy-duty demonstration batteries and insert 2 new "AA" alkaline batteries into the battery compartment located on the body of the Reaper.
- 2. Unravel wire on mounting bracket to the desired length.
- Securely hang mounting bracket. Mounting bracket has multiple holes allowing for a range of mounting capabilities.
- 4. Insert plastic hook located on mounting bracket into the plastic loop located on the top of Reaper.
- 5. Turn switch on Reaper to the "ON" position.
- 6. Gently push the Reaper forward in a circular motion to initiate flight (see "Figure A"). We recommend that you sail your Reaper both counterclockwise and clockwise to see which direction your Flying Reaper™ flies best!

WARNING! STAND CLEAR OF ITEM WHILE OPERATING.

DO NOT HANG ITEM ON UNEVEN SURFACE.

DO NOT PLACE WEIGHT ON ITEM WHILE IN OPERATION.



NARNING! CHOKING HAZARD—Small Parts.

This item is not a toy. For decoration only.

This product is intended for use by persons 15 years of age and older.


Not intended for use by children 14 years of age and younger.

BATTERY INSTRUCTIONS AND CAUTIONS:

- Battery installation and removal should be performed by an adult.
- · Remove batteries when not in use.
- Use only batteries recommended in the instructions.
- · Do not mix new and used batteries.
- Do not mix alkaline, carbon-zinc, nickel-cadmium, rechargeable or different types of batteries.
- Be mindful to insert batteries with the correct polarity (+/-) as indicated.
- Remove all exhausted batteries.
- Rechargeable batteries are only to be charged under adult supervision.

Requires 2 "AA" Batteries

(Included for demo purposes.)



- Rechargeable batteries are to be removed from the item before being charged.
- Non-rechargeable batteries are not to be recharged.

 The control of the cont
- The supply terminals are not to be short-circuited.
- Always dispose of exhausted batteries properly.
- Do NOT dispose of batteries in fire, they may leak or explode.



DO NOT RETURN THIS ITEM TO THE STORE! If experiencing technical difficulties, please go to **tekkydesign.com** for assistance.



TEKKYDESIGN.COM